


# Manual for MyQ Integrated terminal

To log in, enter your PIN or insert your card.




To print from your mobile phone/tablet, install application MyQ X, then just take a picture of the QR tag on the printer panel to automatically set up printing on your device.




MyQ Integrated Terminal Main Menu



<p><b>Print All</b></p> <p><b>PRINT ALL</b> All jobs that are scheduled for printing will be printed.</p>	<p><b>My Jobs</b></p> <p><b>MY JOBS</b> Manage print jobs (select jobs to print, add to favourites, select jobs to delete).</p>	<p><b>Panel USB</b></p> <p><b>PANEL USB</b> Press to enter the USB panel. Print from USB. Scan to USB.</p>	<p><b>Easy Scan - Email</b></p> <p><b>EASY SCAN</b> Press to start instant scanning to PDF, single-sided, color.</p>	<p><b>Panel Scan</b></p> <p><b>SCAN PANEL</b> Press to enter the scanning panel. User configurable scanning - advanced.</p>	<p><b>Panel Copy</b></p> <p><b>COPY PANEL</b> Press to enter the device panel 'COPY'. To start copying, press 'START'.</p>	<p><b>Language</b></p> <p><b>LANGUAGE</b> Change the language of the control panel</p>
---	---	--	--	---	--	--




Printing is possible via the web interface at [myq.lf3.cuni.cz](http://myq.lf3.cuni.cz), the mobile app or via the printer's USB port.




**My jobs**



	Starts printing the marked job(s).
	Add to favourites / remove from favourites
	Printing options - the ability to force duplex printing, B&W printing and the ability to change the number of copies. The icon can be found in the 'My Jobs' menu.
	Mark for deletion To delete, mark one or more jobs and press the 'Trash' button.



**Panel USB**




Start



2

## Scan to USB memory stick

Connect the USB stick to the device. Press the Store File button (1), and then confirm by pressing the START button (2) on the device panel. The scanned document is saved to the USB memory. When you have finished scanning to the USB memory, be sure to select Remove Memory (3).



Start



2

## Printing from a USB memory

Connect the USB memory to the device. Mark the jobs to be printed. Press the Print button (1), and then confirm by pressing the START button (2) on the device panel. The selected jobs will now be printed. When printing is complete, do not forget to select Remove Memory (3).